


Run / Standby Control Panels

The run/standby panel allows one system to run one week and the other one to run the other week. If one system fails, the run/standby panel will start the other one. If the temperature is too high, the panel will also start the 2 systems and enable an audible alarm.



Run / Standby
Control Panel

Technical Information

RUN / STANDBY CONTROL PANELS

MODEL	No. OF SYSTEMS	RUN	STANDBY	HIGH TEMP	ALARM	DIMENSIONS (WxDxH)
PANEL_RS1	2	1	1	YES	YES	400x210x600
PANEL_RS2	3	2	1	YES	YES	500x210x700
PANEL_RS3	4	3	1	YES	YES	500x210x700