

Centralized Remote Controller

Just press a switch to start. All of the units can be On/Off by pressing the main switch, and each unit in the group can be On/Off with individual switch. The PAC-YT40ANRA also has hardwired connection available (On/Off input, fire alarm input, run output, fault output).

ON/OFF remote controller PAC-YT40ANRA



| FUNCTION | DESCRIPTION | PAC-YT40ANRA | |
|-------------------------------------|---|--------------------|---------|
| UNITS | Max No.Units | 50 units/16 groups | |
| | | OPERATIONS | DISPLAY |
| ON/OFF | Run and stop operation | ✓ | ✓ |
| ERROR INDICATION | LED flashes during failure. (The error code can be confirmed by removing the cover.) | - | ✓ |
| VENTILATION OPERATION (INDEPENDENT) | Group operation of only LOSSNAY units possible. *Only ON/OFF of group. | ✓ | ✓ |
| VENTILATION OPERATION (INTERLOCKED) | The LOSSNAY will run in interlock with the operation of indoor unit. *The fan rate and mode cannot be changed. The LED will turn ON only during operation after interlocking. | ✓ | ✓ |
| EXTERNAL INPUT | On/Off/Fire Alarm | ✓ | - |
| EXTERNAL OUTPUT | On/Off/Faults | - | ✓ |

• Dimensions:130(W) x 120(H) x 19(D) mm
:5-1/8(W) x 4-23/32(H) x 3/4(D) in.

- The group setting is kept in nonvolatile memory. No need to worry about re-setting at power failure.
- No individual AC power supply is needed. The power can be supplied from one outdoor unit (R410A) or Power supply unit.

System example

